

INDASH by PANAVISE®

I-75116-604

Page 1 of 1

MOUNTING LOCATION:

Right side of cubby/storage MR

TOOLS REQUIRED:

Hook tool

Stubby or Rt. Angle Screwdriver

HARDWARE INCLUDED:

(3) A - #8X9/16 Needle Point Screw

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: 75116-604

MFG: ACURA

MODELS & YEARS:

TSX 2004-2008

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: Open cubby door and remove rubber mat at bottom of cubby. Insert hook tool into one of the holes in the bottom of cubby and pull to release (4) clips. With cubby door open, pull to release cubby. Angle and pull cubby out, and set aside.

STEP #2: Align the InDash by PanaVise Mount with the right side of the cubby. The joggle of the InDash by Panavise sits on the outside edge of the dash. The top angled corner of the InDash by PanaVise should align with the angle on the wall of the cubby.

STEP #3: Locate the (3) screw holes and insert the (3) screws. Replace the cubby.



Prototype installed showing mounting placement & screws

**INSTALLATION IS NOW COMPLETE.
ENJOY YOUR NEW INDASH by PANAVISE MOUNT.**



Prototype installed showing location



09-05-07

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise *InDash Applications List*: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com. © 2002 PanaVise Products, Inc.