

99-3051

INSTALLATION INSTRUCTIONS



VEHICLE APPLICATIONS

Chevrolet Corvette 1990-96



KIT COMPONENTS

Pocket Trimplate



Pocket



Brackets



(4) #6 x 1/4" Phillips Flat Head Screws

(2) #8 x 3/8" Phillips Pan Head Screws

TOOLS REQUIRED

Phillips screw driver



Dremel



- ISO head unit provision with pocket
- Stacked ISO head unit provision
- Double DIN head unit provision

Questions?

Call the Help Line: **(800)253 TECH**

Monday - Friday 9:00 am - 7:00 pm EST


Saturday - Sunday 10:00 am - 4:00 pm EST

• Dash Disassembly	1
• Kit Features	
• ISO Head Unit Provision with Pocket Assembly	2
• Double DIN Head Unit Provision Assembly	3
• Stacked ISO Head Unit Provision Assembly	4
• Final Assembly	5

99-3051 • Chevrolet Corvette 1990-96


- 1 Disconnect the negative battery terminal to prevent an accidental short circuit.
- 2 Remove (2) screws from A/C vents and remove vents.
See figure **A**
- 3 Lift corners of carpet in center console and remove (2) screws. Remove navigation switch panel/switch mask, exposing (2) screws on top of radio brackets.
- 4 Remove rubber inserts in cup holders and remove screws.
See figure **B**
- 5 Set parking brake and shifter selector to drive.
- 6 Lift center console up and back.
See figure **C**
- 7 Remove (3) screws from radio bezel and remove.
- 8 Remove (2) screws located on sides of console to gain access to radio screws.
- 9 Remove (4) screws attaching radio to dash and remove carefully.

* Remove obstruction from rear of dash cavity as shown in figure **D**






Note: Metra recommends mounting the pocket trimplate with the widest border surface at the top.



- 1 Attach the **Pocket Trimplate** to **Pocket** using (2) #8 x 3/8" **Phillips Pan Head Screws** provided.

See figure A




- 2 Align the holes in upper mounting position of the **Brackets** to the holes in the side of the head unit.

- 3 Use screws provided with head unit to secure the **Brackets**.

See figure B

- 4 Place pocket assembly between **Brackets** beneath radio.



- 5 Align the mounting holes and secure pocket assembly to **Brackets** using (4) #6 x 1/4" **Phillips Flat Head Screws** provided.

See figure C

Place left **Bracket** on head unit(s), align holes and secure using screws provided with head unit(s).

1

See figure A




Repeat sequence on right side.

2

99-3051 • Chevrolet Corvette 1990-96


99-3051 • Chevrolet Corvette 1990-96



- 1 Place left **Bracket** on head unit(s), align holes and secure using screws provided with head unit(s).

See figure **A**

- 2 Repeat sequence on right side.



- 1 Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter and making connections as shown. (Isolate and individually tape off the ends of any unused wires to prevent electrical short circuit.)

See figure **A**

- 2 Re-connect the battery terminal and test the unit for proper operation.
- 3 Mount radio and housing assembly into dash opening using the (4) screws removed during disassembly.
- 4 Reassemble dash in the reverse order of the **Dash Disassembly** on page 1.