



INSTALLATION INSTRUCTIONS FOR PART 95-7953

APPLICATIONS

Suzuki Grand Vitar 2006-2007

95-7953


KIT FEATURES

- Double DIN Radio Provision
- Stacked ISO Mount Units Provision



KIT COMPONENTS

A) Radio Housing • B) Double DIN Brackets • C) Double DIN Trim Plate



TOOLS REQUIRED:

- Small Flat Blade Screwdriver
- Panel Removal Tool
- Phillips Screwdriver
- Socket Set



1-800-221-0932



www.metraonline.com

© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



95-7953

TABLE OF CONTENTS

Dash Disassembly

- Suzuki Grand Vitara 2006-2007.....	1
--------------------------------------	---

Kit Assembly

- Double DIN Radio Provision	2
- Stacked ISO Mount Units Provision	3

<u>Final Assembly</u>	4
------------------------------------	---

***Note:**

Refer also to the instructions included with the aftermarket radio.


SUZUKI GRAND VITARA 2006-2007

**Note: Refer also to the instructions included with the aftermarket radio.*


- 1 Disconnect the negative battery-terminal to prevent an accidental short circuit.
- 2 Unclip and remove the (2) outside trim panels. (Figure A)
- 3 Remove (6) Phillips screws securing the radio and climate controls to the sub dash. Unplug and remove radio/climate control assembly. (Figure B)
- 4 Remove the (2) Phillips screws securing the factory radio bracket to the radio/climate control assembly. (Figure C)
- 5 Separate the bracket and factory radio from the climate control. (Figure D)

Continue to kit assembly.


A




B



C



D





95-7953 KIT ASSEMBLY



DOUBLE DIN RADIO PROVISION

****Note:** Refer also to the instructions included with the aftermarket radio.*

NOTE: Mount the radio housing to the climate control assembly using the factory screws removed in step 4 of dash disassembly.

- 1** Snap the Double DIN brackets to the inside edge of the Double DIN trim plate. (Figure A)
- 2** Slide the Double DIN radio into the bracket/trim plate assembly and secure the radio to the assembly using the screws supplied with the radio. (Figure B)
- 3** Snap the Double DIN trim plate onto the front of the housing/radio assembly. (Figure B)

Continue to final assembly.







STACKED ISO MOUNT UNITS PROVISION

****Note:** Refer also to the instructions included with the aftermarket radio.*


NOTE: Mount the radio housing to the climate control assembly using the factory screws removed in step 4 of dash disassembly.

- 1** Snap the Double DIN brackets to the inside edge of the Double DIN trim plate. (Figure A)
- 2** Slide the stacked ISO units into the bracket/radio housing assembly and secure the units to the kit using the screws supplied with the units. (Figure B)
- 3** Snap the Double DIN trim plate onto the front of the housing/radio assembly. (Figure B)

Continue to final assembly.



FINAL ASSEMBLY



(A) Strip wire ends back 1/2"

B) Twist ends together

C) Solder

D) Tape

- 1** Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter and making connections as shown. (Isolate and individually tape off the ends of any unused wires to prevent electrical short circuit.)
- 2** Re-connect the negative battery terminal and test the unit for proper operation.
- 3** Reassemble radio and dash assemblies in reverse order of disassembly.

FINAL WIRING CONNECTIONS

Make wiring connections using the EIA color code chart shown below and the instructions included with the head unit. Metra recommends making connections as shown below; Strip, Splice, Solder, Tape. Isolate and individually tape off ends of any unused wires to prevent electrical short circuit.

METRA / EIA WIRING CODE

12V Ignition / Acc.	Red	Right Front (+)	Gray
12V Batt / Memory.	Yellow	Right Front (-).	Gray/ Black
Ground.	Black*	Left Front (+)	White
Power Antenna.	Blue	Left Front (-).	White / Black
Amp Turn-On	Blue / White	Right Rear (+)	Violet
Amp Ground.	Black / White	Right Rear (-).	Violet / Black
Illumination	Orange	Left Rear (+)	Green
Dimmer	Orange / White	Left Rear (-).	Green / Black

***NOTE:** When a Black wire is not present, ground radio to vehicle chassis.

All colors may not be present on all leads due to manufacturer's specifications.



95-7953

NOTES

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

95-7953 INSTRUCTIONS



1-800-221-0932



www.metraonline.com

REV. 01/05/07 © COPYRIGHT 2004 METRA ELECTRONICS CORPORATION

INST95-8211