



INSTALLATION INSTRUCTIONS FOR PART 99-3304

APPLICATIONS

**2005-2007 Chevrolet Uplander
2005-2007 Buick Terraza
2005-2006 Saturn Relay
2005-2007 Pontiac Montana (SV6 only)
2005-2007 Chevrolet Corvette
2006-2007 Hummer H3**

99-3304






KIT FEATURES

- DIN Head Unit Provisions with Pocket
- ISO DIN Head Unit Provisions with Pocket




KIT COMPONENTS

A) Radio Housing • B) ISO Brackets • C) Trim Plate



TOOLS REQUIRED:

Socket Wrench • Flat Blade Screwdriver • Phillips Screwdriver



1-800-221-0932



www.metraonline.com

© COPYRIGHT 2004-2007 METRA ELECTRONICS CORPORATION




99-3304

TABLE OF CONTENTS

<i>Dash Disassembly</i>	<i>1-3</i>
<i>Kit Assembly</i>	<i>4-5</i>
<i>Final Assembly</i>	<i>6</i>


CHEVY UPLANDER, PONTIAC MONTANA
SV6, BUICK TERRAZA 2005-2007/
SATURN RELAY 2005-2006

- 1** Disconnect the negative battery terminal to prevent an accidental short circuit.
- 2** Unclip and remove trim panel around radio and a/c control. (Figure A)
- 3** Remove (8) 9/32" screws to extract radio and a/c control from sub dash. (Figure A)





2005-2007 CHEVROLET CORVETTE

- 1 Disconnect the negative battery terminal to prevent an accidental short circuit.
- 2 Unclip and remove ride control switch/blank plate at front edge of center console lid. (Figure A)
- 3 Remove (2) 9/32" screws from under plate removed in step 2. (Figure A)
- 4 Unclip and remove entire panel surrounding radio and including a/c controls. (Figure A)
- 5 Remove (4) 9/32" screws securing radio to extract from sub dash. (Figure A)



2006-2007 HUMMER H3





- 1 Disconnect the negative battery terminal to prevent an accidental short circuit.
- 2 Unclip and remove trim panel around radio and a/c controls. (Figure A)
- 3 Remove (4) 9/32" screws securing radio. (Figure B)
- 4 Unplug and remove radio.

DASH DISASSEMBLY



DIN HEAD UNIT PROVISIONS

- 1 Slide the DIN cage into the Radio Housing and secure by bending the metal locking tabs down. (Figure A)
- 2 Slide the aftermarket head unit into the cage and secure. (Figure B)



ISO DIN HEAD UNIT PROVISION

- 1** Mount the ISO Brackets to the head unit with the screws supplied with the unit. (Figure A)
- 2** Slide the head unit into the radio opening until the side clips engage. (Figure B)
- 3** Snap the Trim plate into the Radio Housing. (Figure B)


A**B****KIT ASSEMBLY**

FINAL ASSEMBLY

- 1 Locate the factory wiring harness in the dash and make the connection as shown. Metra recommends using the proper mating adapter and making the connections as shown. (Isolate and individually tape off the ends of any unused wires to prevent electrical short circuit.)
- 2 Re-connect the negative battery terminal and test the unit for proper operation.
- 3 Reassemble radio and dash assemblies in reverse order of disassembly.

FINAL WIRING CONNECTIONS

Make wiring connections using the EIA color code chart shown below and the instructions included with the head unit. Metra recommends making connections as shown below; Strip, Splice, Solder, Tape. Isolate and individually tape off ends of any unused wires to prevent electrical short circuit.



- A) Strip wire ends back 1/2"**
- B) Twist ends together**
- C) Solder**
- D) Tape**

METRA / EIA WIRING CODE

12V Ignition / Acc . . . Red
 12V Batt / Memory . . Yellow
 Ground Black*
 Power Antenna Blue
 Amp Turn-On Blue / White
 Amp Ground Black / White
 Illumination Orange
 Dimmer Orange / White

Right Front (+) Gray
 Right Front (-) Gray / Black
 Left Front (+) White
 Left Front (-) White / Black
 Right Rear (+) Violet
 Right Rear (-) Violet / Black
 Left Rear (+) Green
 Left Rear (-) Green / Black

***NOTE:** When Black a wire is not present, ground radio to vehicle chassis.
 All colors may not be present on all leads due to manufacturer's specifications.

[illegible]



99-3304

NOTES

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



99-3304

NOTES

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

99-3304 INSTRUCTIONS



1-800-221-0932



www.metraonline.com

REV. 06/26/07

© COPYRIGHT 200-20074 METRA ELECTRONICS CORPORATION

INST99-3304