



INSTALLATION INSTRUCTIONS FOR PART 99-82295

APPLICATIONS

2011 TOYOTA SIENNA

99-82295





KIT FEATURES

- ISO DIN Head unit provision with pocket
- DDIN Head unit provision
- Painted silver to match factory dash



KIT COMPONENTS

• A) Radio Housing • B) Radio Housing Brackets • C) Pocket • D) (8) #8 3/8" Phillips Screws



WIRING & ANTENNA CONNECTIONS (Sold Separately)

- TYTO-01 - Toyota Interface 2006-up
- 70-1761 - Toyota Harness

TOOLS REQUIRED

- Panel Removal Tool
- Phillips Screwdriver
- Flat Blade Screwdriver
- Socket Wrench



METRA. THE WORLD'S BEST KITS.™



1-800-221-0932



metraonline.com

© COPYRIGHT 2004-2010 METRA ELECTRONICS CORPORATION



TABLE OF CONTENTS

DASH DISASSEMBLY

- 2011 TOYOTA SIENNA 1-2

KIT ASSEMBLY

2011 TOYOTA SIENNA

- ISO DIN HEAD UNIT PROVISION 3-4
- DDIN HEAD UNIT PROVISION 5

CAUTION : Metra recommends disconnecting the negative battery terminal before beginning any installation. All accessories, switches and especially air bag indicator lights must be plugged in before reconnecting the battery or cycling the ignition.

***NOTE:** Refer also to the instructions included with the aftermarket radio.



KNOWLEDGE IS POWER

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.






Metra recommends MECP certified technicians

99-82295 DASH DISASSEMBLY

2011 TOYOTA SIENNA

- 1** Unclip and remove the trim panel above the glove box and below the a/c control. (Fig. A)
- 2** Unclip and remove the shifter trim panel. (Fig. B)
- 3** Unclip and remove the a/c control. (Fig. C)





Continued on PG. 2

99-82295 DASH DISASSEMBLY

2011 TOYOTA SIENNA

- 4** Remove (4) 10 MM bolts securing the radio. (Fig. D)

- 5** Remove the (4) Phillips screws securing the outer a/c vent trim panel to the factory radio and separate. (Fig. E)






Continue to Kit Assembly



99-82295 KIT ASSEMBLY

ISO DIN HEAD UNIT PROVISION

- 1** Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter from Metra or AXCESS. Re-connect the negative battery terminal and test the unit for proper operation.
- 2** Secure the radio housing brackets to the radio housing with four #8 3/8" Phillips screws provided. (Fig. A)
- 3** Attach the pocket to the bracket/radio housing assembly with the four #8 3/8" Phillips screws provided. (Fig. B)
- 4** Align the holes in the radio housing brackets with the holes in the ISO DIN Head Unit and secure the brackets to the head unit with the screws included with the unit. (Fig. C)




Continued on PG. 4



99-82295 KIT ASSEMBLY

ISO DIN HEAD UNIT PROVISION

- 5** Attach the outer a/c vent trim panel to the radio housing using the factory hardware. (Fig. D)
- 6** Reassemble dash in reverse order of disassembly.





99-82295 KIT ASSEMBLY

DDIN HEAD UNIT PROVISION




- 1** Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter from Metra or AXCESS. Re-connect the negative battery terminal and test the unit for proper operation.

- 2** Secure the radio housing brackets to the radio housing with four #8 3/8" Phillips screws provided. (Fig. A)

- 3** Slide the Double DIN head unit into the bracket/radio housing assembly and secure the Double DIN head unit to the assembly using the screws supplied with the radio. (Fig. B)

Attach the outer a/c vent trim panel to the radio housing using the factory hardware. (Fig. C)

- 5** Reassemble dash in reverse order of disassembly.





INSTALLATION INSTRUCTIONS FOR PART 99-82295

REV. 10/4/2010

METRA. THE WORLD'S BEST KITS.™



1-800-221-0932



metraonline.com

© COPYRIGHT 2004-2010 METRA ELECTRONICS CORPORATION